

Revision A September 2001—First Printing (ECN Released)
Revision B November 2001—Second Printing

2300™ Microwave Strip Module Facility

PUBLISHED BY
Publications Department
Lam Research Corporation
4650 Cushing Parkway
Fremont, California 94538-6470
E-mail: pubs@lamrc.com

Copyright ©2001 by Lam Research Corporation. Printed in the United States of America. All Rights Reserved.

The information conveyed in this document has been carefully checked and is believed to be reliable at the time of printing. However, Lam Research Corporation makes no warranty regarding the information set forth in this document and assumes no responsibility for any errors or inaccuracies contained herein. Lam Research Corporation is not obligated to update or correct any information contained in this document. Lam Research Corporation reserves the right to change products or specifications at any time without notice.

Modifications to Lam products may affect their safe operation and may also affect compliance with various laws and regulations governing their operation. To reduce the likelihood of interference, RF transmitters (cellular telephones, CB radios, cordless telephones) should not be used in the vicinity of Lam products.

Lam recommends that customers check with local fire departments within their jurisdictions to ensure all marking requirements are satisfied.

No part of this document may be reproduced in any form for any purpose without the prior written permission of Lam Research Corporation.

2300, 384T, 4520XLE, Advanced Capability Rainbow, Alliance, AutoEtch, Classic, CoolPORT, Continuum, DSS, DSS-150, DSS-200, Deep SubMicron and DSP, EndPoint Plus, Envision, Envoy, Exelan, the Lam logo, Oxide, Rainbow, Synergy, Synergy Integra, Teres, Transformer Coupled Plasma, TCP, and Versys are trademarks of Lam Research Corporation. All other trademarks or registered trademarks are the property of their respective holders. Mention of third-party products or services is for informational purposes only, and does not constitute an endorsement or recommendation.


Part Number: 405-240351-001

PM BOM Version 571-801736-700
Ship With Integration BOM Version 573-802896-701
2300 Etch System Software Version 1.4.3
System Version 2300


Revision B
November 2001

Contents

253-801736-701 Revision A, 2300 Microwave Strip Module Facility Specification	1
224-801736-700 Revision B, 2300 Microwave Strip Module Interconnect Diagram	5
224-801736-702, Revision A, Interconnect Diagram, PM to Rack Generator, 2300 Microwave Strip Module	15
251-801736-700 Revision B, P&ID Diagram, 2300 Microwave Strip Module	17







8		7		6		5		4		3		2		1	
TABLE 1 PHYSICAL DIMENSIONS															
DESCRIPTION	WIDTH IN	MAX CM	DEPTH IN	MAX CM	HEIGHT IN	MAX CM	WEIGHT LBS		KG						
STRIPPER	35.5	90.2	25.3	64.3	71.5	181.6	560	255							
TABLE 2 ENVIRONMENT															
DESCRIPTION	TEMPERATURE		HUMIDITY		VIBRATION										
	°C	±	%		SENSITIVE	EMISSION									
STRIPPER	25	5	<50		SLIGHT	NO									
TABLE 3 THERMAL OUTPUT															
DESCRIPTION	(BTU/hr)														
	CARRIED BY WATER		CARRIED BY EXHAUST		DISPERSED TO ENVIRONMENT		TOTAL OUTPUT								
STRIPPER	TBD		TBD		TBD		TBD								
TABLE 4 POWER REQUIREMENTS															
DESCRIPTION	VOLTS (AC)	Hz	PHASE	WIRE	TYPE	AMPS	CONDUIT REQUIRED								
STRIPPER	208 $\pm 10\%$ -15%	50/60	3	6	WYE	50	1" FLEX								
TABLE 5 VACUUM REQUIREMENTS															
DESCRIPTION	PRESSURE ULTIMATE VAC (TORR)		FLOW MAX (SLM)		FLOW AVG. (SLM)		CONNECTOR								
STRIPPER	<.02		10.0		4.0		NW100								
TABLE 6 HELIUM															
DESCRIPTION	FLOW (SCCM)	PRESSURE (PSI)	FITTING SIZE TYPE		SOURCE	USAGE	FILTER (MICRON)								
N/A	N/A	N/A	N/A		N/A	N/A	N/A								
TABLE 7 NITROGEN															
DESCRIPTION	FLOW (SLM)	PRESSURE (PSI)	FITTING SIZE TYPE		SOURCE	USAGE	FILTER (MICRON)								
PUMP BALLAST	84	50±5	1/4" COMPRESSION (PFA)		HOUSE	PULSED	.05								
TABLE 8 CLEAN DRY AIR (CDA)															
DESCRIPTION	FLOW (SLM)	PRESSURE (PSI)	FITTING SIZE TYPE		SOURCE	USAGE	FILTER (MICRON)								
PNEUMATIC SYSTEM	10±4	90±5	3/8" SWAGELOCK		HOUSE	PULSED	30								
TABLE 9 PROCESS GASES (FROM GASBOX)															
GAS #	CHEM. SYM.	PURITY (%)	FLOW RATE (SCCM)		REG. PRESS. (PSI)	SENS. TO LEAK	FILTER (MICRON)		FITTING (FEMALE)						
1	O ₂	99.998	5000		20±5	YES	≤.01		1/4 VCR						
2	N ₂	99.998	1000		20±5	YES	≤.01		1/4 VCR						
3	CF ₄	99.998	1000		20±5	YES	≤.01		1/4 VCR						
4	NH ₃	99.998	1000		20±5	YES	≤.01		1/4 VCR						
TABLE 10 SYSTEM SCRUBBER EXHAUST REQUIREMENTS (.0PT)															
DESCRIPTION	FLOW (CFM)	H ₂ O (IN)	SYSTEM	HAZARD	DUCT SIZE		REMOVABLE	OIL CONTENT							
					IN.	CM.									
STRIPPER	75	SEE ETCH	N/A	YES	4"	10.2	N/A	N/A							
TABLE 11 WATER/COOLANT FLOW SPECIFICATIONS															
DESCRIPTION	FLOW			PRESS. PSI	MIN. DIFF. PRESS. PSID	TEMPERATURE									
	GPM	L/MIN	±			°C	±								
WATER IN	5	18.9	±5 GPM OR 2 L/MIN	70 PSI	N/A	20	5								
WATER OUT	N/A	N/A	N/A	VARIES	N/A	N/A	N/A								
TABLE 12 WATER/COOLANT INTERFACE HARDWARE REQUIREMENTS															
DESCRIPTION	FITTING			LINE		FILTER (MICRON)									
	SIZE	TYPE		SIZE	TYPE										
WATER IN	1/2"	SWAGELOK		1/2"	POLY	50±5 LBS									
WATER OUT	1/2"	SWAGELOK		1/2"	POLY	N/A									
MAX. RECOMMENDED PARTICLE SIZE IN WATER: 75 MICRONS															
TABLE 13 ULTRAPURE DI WATER FLOW SPECIFICATIONS															
DESCRIPTION	FLOW			PRESS. PSIG	MIN. DIFF. PRESS. PSID	TEMPERATURE									
	GPM	L/MIN	±			°C	±								
WATER IN	.01	.03	5±	50±10	N/A	20	5								
WATER OUT	.01	.03	5±	VARIES	1	20	5								
TABLE 14 ULTRAPURE DI WATER INTERFACE HARDWARE REQUIREMENTS															
DESCRIPTION	FITTING			LINE		FILTER (MICRON)									
	SIZE	TYPE		SIZE	TYPE										
WATER IN	3/8"	COMPRESSION(PFA)		3/8"	TEFLON HOSE	10 MICRONS CANNISTER PRE FILTER ON FACILITIES SUPPLY									
WATER OUT	3/8"	COMPRESSION(PFA)		3/8"	TEFLON HOSE	N/A									
MAX. RECOMMENDED PARTICLE SIZE IN WATER: 5 MICRONS															
TABLE 15 FLOOR LOADING															
DESCRIPTION															
FRONT LEVELERS (2)		280 LBS													
REAR LEVELERS (2)		280 LBS													
CHART #1 REMOTE POWER/EMO CABLE CONNECTIONS															
SYSTEM EMO INTERFACE CABLE (TO EMO DISTRIBUTION)															
GAS BOX DC POWER CABLE															
PM-MAIN POWER INTERFACE CABLE (TO AC RACK)															
CHART #2 REMOTE UMF/NODE/INTER LOCK CABLE CONNECTIONS															
GAS BOX INTERLOCK CABLE															
TM-ETHERNET COAX CABLE															
GAS BOX LONWORKS CABLES															
PUMP LONWORKS CABLES															
TM-INTERLOCK CABLE															
Lam Corporation FREMONT, CA SIZE D DRAWING NO. 253-801736-701 REV A SCALE NONE SHEET 4 OF 4															

STRIP ASSEMBLIES			STRIP MISCELLANEOUS		
ASSY REF DES	ASSEMBLY	SHEET NO.	ASSY REF DES	ASSEMBLY	SHEET NO.
A1	VME CONTROL ENCLOSURE	003.005.006.008	A40	VODM	002.004.007
A2	AC CONTROL ENCLOSURE	002.003.004.005	A44	BUTTERFLY VALVE	008
A3	DC CONTROL ENCLOSURE	002.003.	A46		
A4			A47	GENERATOR RACK ASSY	
A5	REACTION CHAMBER	004.007.008	A60	ACTUATOR/TOP LID	003.004
A6	UPPER CHAMBER	004	A61	CONTROL BOX UP/DN	003.004
A7	MICROWAVE SOURCE	003.004.008			
A8					
A9					
A17	PNEUMATIC MANIFOLD	007			
A21	CHAMBER SIGNAL/INTLCK	003.005.006.007			
A30					

REMOTE EQUIPMENT		
ASSY REF DES	ASSEMBLY	SHEET NO.
A7A4	TM/PM INTERFACE BRACKET	003.005
A41	FM INTERFACE BRACKET	005.006

REVISIONS						
REV	ZONE	DESCRIPTION	INC BY	CHECK	APVD	DATE
A		INITIAL RELEASE	HB	NG	SG	7/7/01
B		UPDATES FOR RACK	HB			

NOTES:

- P/O DENOTES "PART OF".
- ZONE LOCATING SYMBOL:
DASH NO.

-002	6
	B

 HORIZONTAL ZONE
VERTICAL ZONE.
- PARTIAL REFERENCE DESIGNATION:

A2	2J2
----	-----

ASSEMBLY →
CONNECTOR DESIGNATION →
- CONNECTOR DESIGNATION TO BE PREFIXED WITH ASSEMBLY REFERENCE DESIGNATION NUMBER ONLY. LETTER "A" NOT REQUIRED.

COVER, NOTES, TABLES, ETC

DRWN	INITIAL	DATE
M. BUCARINI	HB	5/1/01
CHECKED		
M. SIKMA	NG	6/1/01
ELECT. ENGINEER		
S. SHAFARI	SG	6/5/01
MECH. ENGINEER		

Lam RESEARCH FREMONT, CA

TITLE (NO CHG. INCL)
DIAG. INTCON, 2300 STPR, MICROWAVE

SIZE D DRAWING NO. 224-801736-700 REV B


ALL DIMENSIONS ARE IN INCHES
DIMENSIONS IN () ARE MILLIMETERS.

SCALE NONE SHEET 1 OF 4


DOC. CONTROL
JUL 10 2001
RELEASED

LAM PROPRIETARY INFORMATION
THIS DOCUMENT AND THE INFORMATION CONTAINED HEREIN
ARE CONFIDENTIAL TO, AND THE PROPERTY OF, LAM RE-
SEARCH CORPORATION. THIS DOCUMENT SHALL BE DISCLOSED
ONLY AS NECESSARY TO CARRY OUT THE PURPOSE FOR
WHICH IT WAS DISCLOSED AND IN A MANNER TO PROTECT
ITS CONFIDENTIALITY. NO OTHER USE IS PERMITTED.
THIS DOCUMENT SHALL BE RETURNED IMMEDIATELY UPON
LAM'S REQUEST.


Released
Printed: Mon Aug 27 15:32:32 GMT 2001
See ECO File (RF, L, 220) for Current Rev Status




Released
Printed: Mon Aug 27 15:32:39 GMT 2001
See ECO File (MF,1,220) for Current Rev Status




Released
Printed: Mon Aug 27 15:32:46 GMT 2001
See ECO File (WF,I,220) for Current Rev Status



Released
Printed: Mon Aug 27 15:32:54 GMT 2001
See KCO File (NF,L,220) for Current Rev Status



Released
Printed: Mon Aug 27 15:33:01 GMT 2001
See ECO File (Mr, L, 220) for Current Rev Status




Released
Printed: Mon Aug 27 15:33:08 GMT 2001
See ECO File (MF, L, 220) for Current Rev Status




Lam Research Corporation
FREMONT, CA


SIZE	D	DRAWING NO.	224-801736-700	REV	B
SCALE	NONE	SHEET 6 OF 9			




Released
Printed: Mon Aug 27 15:33:15 GMT 2001
See ECO File (MF,L,220) for Current Rev Status




Released
Printed: Mon Aug 27 15:33:21 GMT 2001
See ECO File (MF,L,220) for Current Rev Status




Released
Printed: Mon Aug 27 15:33:28 GMT 2001
See ECO file (EP, L, 220) for Current Rev Status




Released 2001/08/31-21:49:11:537 224-801736-702
Printed: Thu Oct 25 21:04:03 GMT 2001
See ECO File (MF, L, 220) for Current Rev Status





Released
 PPrinted: Mon Aug 27 15:35:36 GMT 2001
 See ECO File (MF,L,220) for Current Rev Status



Released
Printed: Mon Aug 27 15:35:43 GMT 2001
See ECO file (NF, L, 220) for Current Rev Status

For additional information,
contact the closest Lam Research Corporation Office

DOMESTIC OFFICES

Corporate

CA Fremont (1) (510) 659-0200

Central Region

TX Austin (1) (512) 634-3100
TX Richardson (1) (972) 644-1717
MN Bloomington (1) (612) 858-7225

Eastern Region

MA Westborough (1) (508) 898-2090
NY Fishkill (1) (914) 896-0606
VT Williston (1) (802) 879-1153
FL Orlando (1) (407) 438-8448
VA Manassas (1) (703) 392-6403
ME South Portland (1) (207) 828-9462

Northwestern Region

ID Boise (1) (208) 373-7400
OR Aloha (1) (503) 642-8671
WA Vancouver (1) (360) 260-9600

Southwestern Region

AZ Tempe (1) (480) 921-7373
CO Colorado Springs (1) (719) 577-4480
NM Albuquerque (1) (505) 857-0391

Western Region

CA Costa Mesa (1) (714) 641-1871
CA Fremont (1) (510) 572-5500
CA Milpitas (1) (510) 572-6109

JAPANESE OFFICES

Lam Research Co., Ltd.—Headquarters

Kanagawa Sagamihara-shi (81) (427) 70-0320

Lam Research Co., Ltd.

Kanagawa Sagamihara-shi (81) (427) 70-0321
Kanagawa Sagamihara-shi (81) (427) 70-0326
Ibaragi-ken Tsuchiura-shi (81) (298) 41-5930
Mie-ken Yokkaichi-shi (81) (593) 55-6170
Miyagi-ken Sendai-shi (81) (222) 18-2770
Hiroshima-ken Fukuyama-shi (81) (849) 28-9870
Toyama-ken Toyama-shi (81) (764) 44-2250
Osaka Osaka-shi (81) (6) 305-0052

EUROPEAN OFFICES

Lam Research SARL

France Meyaln (33) (0) 476-614-900
France Le Coudray (33) (0) 164-93-7400
Montceaux

Lam Research GmbH

Germany Munich (49) (0) 89-96099-0

Lam Research (Ireland) Limited

Ireland Dublin (353) (1) 4579-186

Lam Research (Israel)

Israel Natanya (972) (9) 8-659-085

Lam Research SRL

Italy Agata Li-Battiat, CT (39) (95) 7254313
Italy Agrate Brianza-MI (39) (039) 657041
Italy Marsicana, AQ (39) (863) 412330

Lam Research BV

The Nijmegen (31) (24) 372-7110
Netherlands

Lam Research Ltd.

Scotland East Kilbride (44) 13552-34430
Bristol Almondsbury (441) (454) 878-712

PACIFIC RIM OFFICES

Lam Research China

PRC Beijing (86) (10) 6510-2990

Lam Research Shanghai

PRC Shanghai (86) (21) 6443-8581

Lam Research Korea Ltd

Sungnam Kyungki-Do (82) (342) 710-6600

Lam Taiwan

ROC Hsin-chu (886) (35) 798666
ROC Hsin-chu (886) (35) 346123

Lam Singapore Pte, Ltd.

Singapore (65) 481-0002

► To send e-mail,

Publications Department pubs@lamrc.com
TSIC Support tsic@lamrc.com
Lam Tech Center lamtechcenter@lamrc.com
Video Department video@lamrc.com

► For emergency assistance,

Lam Tech Center (1) (510) 572-2020
Field Service (1) (800) 526-4357
Customer Service (Parts) (1) (800) 526-4357

